

Neckring Sleeve/Neckring Skirt Assembly Instructions



Step 1: Add a bead of adhesive to the inside of the Neckring skirt/Neckring sleeve.

Step 2: Place Neckring skirt/Neckring sleeve over the existing neckring. Press down firmly.



Step 3: Peen over the three locking tabs into the threads of the existing neckring.

Quickly re-identify your high pressure gas cylinders.
Customize the lettering on the skirt with your company
name and phone number.

For pricing or information contact:
C R Industries, Inc. www.crintustriesinc.com
414-744-3996
Email: crind@crindustriesinc.com

